

Maintenance instruction Schäfer staff airlock furniture Typ VK

Dear customers,

You have purchased a product from us that is characterized by its high quality and durability. To ensure that you can enjoy this product for a long time, we would like to give you a few helpful tips on care:

- Under no circumstances should aggressive, acidic or alkaline cleaners that attack the surfaces be used for basic cleaning. The cleaners used must be free of halogens (chloride and fluoride ions), i.e. they must not contain hydrochloric or hydrofluoric acid (e.g. often found in cement residue removers). These cleaners attack the aluminum and stainless-steel parts and lead to corrosion. **Special stainless steel care products are available from us.**
- In extreme conditions, e.g. in rooms with aggressive air, etc., stainless steel must also be cleaned from time to time to prevent the build-up of deposits, which can lead to pitting corrosion in the long term.
- The elements can be cleaned with commercially available PH-neutral household cleaners. These should be used for regular cleaning. In the case of stubborn soiling with grease, graffiti, etc., spirit or isopropanol can be used for cleaning. **Special graffiti removers are available from us.**
- Slightly alkaline cleaners are suitable for periodic cleaning. Make sure that the cleaners are not acidic so that the surface is not attacked.
- To ensure that the gloss of the profiles and the surface is not lost, scouring agents or scouring milk must not be used under any circumstances.
- Suitable tools are soft, clean sponges, leather, cloths or rubber wipers. The use of sharp, metallic objects can damage the surface.
- We strongly recommend wiping the elements dry with a rubber scraper or soft cloth after cleaning to prevent the build-up of limescale.
- All moving parts are maintenance-free and do not need to be greased.
- In some construction projects, joints are made with permanently elastic materials. These joints are maintenance joints that must be regularly checked and maintained by those responsible for the building. Particularly in wet areas or in areas with permanently high humidity and heat or where aggressive cleaning agents are used, the joints must be cleaned thoroughly with clear water on a regular basis, depending on the amount of use, e.g. to remove soap residues or cleaning agent residues. The joints should then be wiped with a commercially available disinfectant and then rubbed dry. Rooms with high humidity and heat must be sufficiently ventilated on a regular basis.

If you have any further questions about the care and maintenance of our systems, please do not hesitate to contact us. We hope you enjoy your new airlock furniture!

Your Schäfer team